

F-525

Maintenance Schedule

Service Daily

Ref#

1. Engine Oil (2) Check TWICE Daily, Cap. = 27 oz(approx. 7/8 Quart). Do not overfill; excess oil will only blow out of the breather. Change oil every 50 hours of use. Use L.P. Gas Engine Oil, SAE 30. If L.P. oil is not available, use a low ash, mild detergent type oil. 10 w 30 oil is acceptable; DO NOT USE 10 w 40.
2. Electric Hyd. System (1) Cap. = 2 Gal. Use international Harvester "Hy-Tran", or comparable oil. DO NOT MIX BRANDS.
3. Auger System Hyd. Oil (1) Cap. = 11 ½ quart. Use International Harvester "Hy-Tran", or comparable oil. DO NOT MIX BRANDS.
5. Extension Pinion Shaft Bearings (6) Grease.
6. Auger Shaft Bearings (2) Use HIGH TEMPERATURE Grease.
8. Screed Screw Bearings (2) Grease.
12. Side Roll Bearings (2) Grease.
13. Rim Roll Bearings (2) Grease.

Service Weekly

1. Engine Oil (2) Change Oil every 50 hrs.
- 1A. Engine Air Filter Element (2) Check weekly, replace as needed.
4. Shut off Gate Shaft Bearings (3) Grease.
7. Screed Screw Nut (2) Grease.
9. Extension Slide Tubes (4) Grease.
10. Walking Beam Pivot Pin (2) Grease.

Service Every 250 Hours

2. Electric Hyd. Oil (2) Change Oil.
3. Auger System Hyd. Oil (1) Change Oil.
- 3A. Auger System Hyd. Oil Filter (1) Replace Gresen #K22001.

Service Yearly

11. Wheel Bearings (8) Repack.